

M5 Series


Front Loader

M5-091 – M5-111




Front Loader LA1854 (M5-091/M5-111)

The M5 Series Front Loader puts power and visibility front and center.



Standard and Euro Quick Couplers

This standard M-Series feature makes attaching buckets, bale spears and pallet forks quick and easy. A Euro type quick coupler is optionally available.



4-Bar Linkage

Thanks to an upgraded 4-bar bucket linkage, the rollback and dumping angle has been increased for quicker scooping and dumping.



Loader Lever

Conveniently located in the central console, the Loader Lever provides quick and easy control loader operations.

M5 Series

Front Loader

M5-091 – M5-111



Quick-Mount Attach/Detach

Attach or detach the front loader in moments without the use of tools. The boom stands and mounting pins make this task a snap, allowing an extra measure of productivity and tractor versatility. A single-lever valve hose Quick Coupler (option), available for the loader's hydraulic fittings, allows you to release all four lines at once.



Single-lever Hydraulic Quick Coupler (Optional)

The quick coupler allows the operator to attach all four hoses at once. This makes attaching and detaching quick and easy, even when you're doing it often.